



998 REBUILD KIT WITH COMBUSTOR



Items included in this kit

Description	Part #	Quantity
#2 O-RING	190020	1
#6 O-RING	190060	2
RETAINER	190070	2
LEFT HOUSING W / LABEL	190160	1
RIGHT HOUSING W / LABEL	190150	1
TRIGGER IGNITER	198170	1
SAFETY	190200	1
ASSEMBLY SCREWS	190290	10
BUTTON	190310	1
#33 O-RING	190330	2
COMBUSTOR W / SCREEN	19830A	1

TOOLS NEEDED

- 1 PC #2 PHILLIPS SCREWDRIVER
- 1 PC SMALL JEWELERS PHILLIPS SCREWDRIVER
- 1 PC FLAT HEAD SCREWDRIVER

PLEASE REFER TO YOUR MANUAL PAGES 26 – 29 FOR INFORMATION ON PART NUMBERS REFERENCED
IN THE INSTRUCTION SHEET



REPAIR PROCEDURE

1. REMOVE THE COMBUSTOR



2. REMOVE ALL 10 ASSEMBLY SCREWS FROM THE HOUSING

3. REMOVE STRAP, BUTTON AND BOTH #33 ORINGS



4. REMOVE PHILLIPS SCREW FROM #27 SOCKET WITH SMALL JEWELERS SCREWDRIVER. YOU CAN THEN REMOVE THE IGNITER WIRE.





5. YOU ARE NOW READY TO REASSEMBLE THE BOSOY. START BY INSERTING THE WIRE LEAD FROM THE TRIGGER/IGNITER. WHEN THE WIRE IS FULLY INSERTED REPLACE THE SMALL SPRING AND SCREW. DO NOT STRIP THE WIRE.



6. REPLACE #33 O-RINGS AND REPLACE THE OLD BUTTON AND THE #35 SPRING WITH THE NEW BUTTON. PLACE THE BUTTON AND SPRING ON TOP OF THE BODY AND REPLACE THE #34 STRAP. BE SURE THAT THE BUTTON IS CENTERED WHEN REPLACING THE STRAP.



7. REMOVE THE #7 RETAINER FROM THE #8 INLET AND THE UNDERLYING #6 O-RING. REMOVE THE FILTER HOLDER. CLEAN THE FILTER SCREEN AND REPLACE. REPLACE THE #2 O-RING AND REASSEMBLE. INSERT #6 O-RING AND RETAINER.





ZORMOT
INTERNATIONAL, INC
Premium Shrink Film & Supplies

8. REMOVE THE #7 RETAINER FROM THE #8 VAVLE AND THE UNDERLYING #6 O-RING THEN REPLACE.



9. IT IS NOW TIME TO START REASSEMBLING THE TOOL. BEGIN BY PLACING THE #22 VAVLE, THE #9 FUEL LINE AND INLET ASSEMBLY IN THE LEFT HAND HOUSING.



10. REPLACE THE BODY ASSEMBLY



11. REPLACE THE RIGHT HOUSING AND INSTALL ALL 10 ASSEMBLY SCREWS (BE SURE NOT TO OVER TIGHTEN AS THE HOUSING MAY CRACK).
12. LIGHTLY LUBE THE LAST #33 O-RING WITH VASELINE, WHITE LITHIUM OR O-RING LUBE AND REPLACE THE COMBUSTOR.



ZORMOT
INTERNATIONAL, INC
Premium Shrink Film & Supplies

YOU ARE NOW DONE REBUILDING YOUR 998 HEAT TOOL

REATTACH HOSE, REGULATOR AND INSTALL ON PROPANE TANK. ENSURE THAT THE PRESSURE IS AT LEAST 15 PSI AND YOU ARE NOW READY TO USE YOUR 998 HEAT TOOL.

- The manufacturer and/or distributor have provided the parts list and assembly diagram as a reference tool only. Neither the manufacturer nor distributor makes any representation or warranty of any kind to the buyer that he or she is qualified to replace any parts of this or any other product. The manufacturer and/or distributor expressly states that all repairs and parts replacements should be undertaken by certified and licensed technicians and not by the buyer. The buyer assumes all risks and liability arising out of his or her repairs to the original product or replacement parts thereto, or arising out of his or her installation of replacement parts thereto.

IF YOU ENCOUNTER ANY PROBLEMS DURING THIS PROCEDURE OR REQUIRE FURTHER ASSISTANCE PLEASE CALL ZORMOT INTERNATIONAL INC AT 800-459-5422.